


- 1 MEASURE 3.5" INCHES UP FROM THE INVERT OF THE OUTLET PIPE & MAKE A HORIZONTAL MARK.
- 2 INSERT THE ENVIROHOOD & PLACE THE TOP EDGE OF THE FLANGE ON THE HORIZONTAL MARK. POSITION THE ENVIROHOOD DIRECTLY OVER THE OUTLET PIPE SO THAT THE ENTIRE OUTLET IS COVERED & THE FLANGES OF THE ENVIROHOOD DO NOT BLOCK THE INLET PIPES (SEE DRAWING NO. 7004-110-111 FOR MINIMUM ANGLE BETWEEN ADAPTERS).
- 3 MARK & PRE-DRILL (TO MATCH THE HOLES IN THE ENVIROHOOD) 3/16" PILOT HOLES, FOR THE #14 X 1 1/4" SS SELF TAPPING HEX DRIVE SCREWS, THAT ARE PROVIDED IN THE INSTALL KIT. INSTALL 1/4 X 1" NEOPRENE BACKED WASHERS ON EACH SCREW.
- 4 ATTACH THE ENVIROHOOD TO THE DRAIN BASIN WITH THE #14 SS SCREWS, & TIGHTEN TO APPROXIMATELY 10-15 LBS.

THIS PRINT DISCLOSES SUBJECT MATTER IN WHICH NYLOPLAST HAS PROPRIETARY RIGHTS. THE RECEIPT OR POSSESSION OF THIS PRINT DOES NOT CONFER, TRANSFER, OR LICENSE THE USE OF THE DESIGN OR TECHNICAL INFORMATION SHOWN HEREIN REPRODUCTION OF THIS PRINT OR ANY INFORMATION CONTAINED HEREIN, OR MANUFACTURE OF ANY ARTICLE HEREFROM, FOR THE DISCLOSURE TO OTHERS IS FORBIDDEN, EXCEPT BY SPECIFIC WRITTEN PERMISSION FROM NYLOPLAST.

©2013 NYLOPLAST

DRAWN BY	JJC	MATERIAL
DATE	6-28-13	
APPD BY	JJC	PROJECT NO./NAME
DATE	6-28-13	
DWG SIZE	A	SCALE 1:16 SHEET 1 OF 1

	3130 VERONA AVE BUFORD, GA 30518 PHN (770) 932-2443 FAX (770) 932-2490 www.nyloplast-us.com	
	TITLE ENVIROHOOD FIELD INSTALLATION	
DWG NO.	7004-110-119	REV A